

- Bung
- tie down ratchet strap off
- Light board off
- Outboard bag off
- Rudder on
- Mast untie
- Halyard straps off
- Burgee
- Mast up. Lock mast gate.
- Forestay first
- Shrouds second
- Furlong Genoa up
- Run furling line tie anti twist
- Sort halyards
- Sort lazy jacks
- Blue halyard always behind shrouds
- Blue halyard = front and top cleat
- Red halyard = back and bottom cleat
- Parrell beads tie on luff and jaws as it goes up. Halyards all outside except the Genoa halyard inside the peak jaws.
- Painter on
- Fenders on inside
- Kill cord on engine.
- Remove bow safety line.
- Set up Lowering rope and chocks. Green Strop around trailer with HMS

- Lowering kit away.
- Wheel clamp on
- Van locked
- Key in moon code.